

DIAMOND VIEW® 1995SL

Colour Monitor

19" (48cm) CRT Size

18" (45.7cm) Viewable Area

User's Manual

UG/MO1995SL/0102/2

Table of Contents

1	Important Safety Instructions	1
2	Features	2
3	Unpacking the Monitor	3
4	Installation	3
	Drivers for Windows 95, 98, 2000 and Millennium Edition	4
5	Adjusting the Monitor	5
	Selecting Functions and Making Adjustments	
	Contrast Hotkey	6
	Brightness Hotkey	6
	The Main Menu	6
	Make adjustments	7
	Timing and Refresh Rate Setting	11
	Factory Preset Timings	12
6	Troubleshooting	13
7	Specifications	15
8	Service Contacts	17
	Australian Service Contacts	17
	New Zealand Service Contacts	18

i

Copyright Notice

Copyright 2000, Mitsubishi Electric Australia Pty. Ltd. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission.

Disclaimer

Mitsubishi Electric Australia Pty. Ltd. makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Further, Mitsubishi Electric Australia reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Diamond View is a registered trademark of Mitsubishi Electric Australia Pty. Ltd. Microsoft and Windows are registered trademarks of Microsoft Corporation. All other trademarks remain the property of their respective owners.

Reference Information			
For future reference, write the following information about you monitor in the space below. The serial number is on the back o the product or on the bottom of its stand.			
Monitor Informatio	n		
Product Name:	Diamond View 1995SL		
Serial Number:			
Date of Purchase:			
Dealer Information			
Dealer:			
Telephone Number:			
Address:			

ii

Important Safety Instructions

Please read the following safety instructions before installing or cleaning your Diamond View monitor:

- 1. This monitor must be operated from the type of power source indicated on the rating label. If you are not sure of the type of power available in your area, consult your dealer or local electricity supply company.
- 2. This monitor must be operated with a 3 wire electrical cable that has a plug with a third (grounding) pin. The plug must only be connected to a grounded power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to make the necessary outlet changes. Australian and New Zealand customers should use the power cable supplied with the monitor.
- 3. Make sure that the power outlet that you plug the monitor into is easily accessible.
- 4. Unplug the monitor's power cable from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a soft cloth to clean the monitor housing and screen.
- 5. Slots and openings on the back or top of the cabinet are provided for ventilation. They must not be blocked or covered. This product should never be placed near or over a radiator or other heat source, or in a built-in installation unless proper ventilation is provided.
- 6. Never push objects of any kind, or spill liquid of any kind into the monitor.
- 7. Do not attempt to service the monitor yourself as opening or removing covers may expose you to dangerous voltages or other risks. Removing the cover of the monitor may void warranty.
- 8. If any abnormal operation or an accident (such as dropping the unit) occurs, disconnect the monitor from the wall power outlet and contact qualified service personnel.



Your Diamond View 1995SL Monitor has the following features:

Plug'n Play Compatibility

With DDC1TM and DDC2BTM, the 1995SL is compatible with Plug and Play feature of Microsoft[®] Windows[®] 95, 98, 2000 and Millennium Edition.

• Flicker-free Image

The monitor supports VESA standard graphics signals with flicker-free refresh rates at resolutions up to 1280 x 1024 pixels at 85Hz.

• Larger Viewable Size

With its 45.7 cm (18") viewable size, the 1995SL offers a larger viewable screen area than many other 19" monitors.

• Easy to Use On Screen Display

The On-Screen Display (OSD) allows you to adjust all settings simply with on-screen menus.

Power Saving Function

The power management complies with VESA DPMS standard. When the system is idle (off mode), the monitor automatically cuts its power consumption up to 95%.

Green Commitment

No CFCs are used in the manufacturing process of your monitor. It complies with the US government's Energy Star standards and the rigorous standards of Scandinavian countries.

3 Unpacking the Monitor

Please check that the following items are included with your monitor. If they are missing or damaged, please contact your place of purchase immediately.

- Monitor with attached signal cable
- Power cord
- User's manual


Locate the model name and the serial number label on the back of your monitor and write the details of the monitor and your place of purchase in the space on page (ii) of this manual for future reference.




Your monitor is equipped with an automatic power supply with a voltage range from 100 to 240 Volts AC at a frequency of 50 to 60 Hz.

To install your Diamond View 1995SL monitor:

- 1. Make sure that the computer system's power is turned off.
- 2. Connect the power cord to the monitor and attach it to a power socket.



3. Connect the computer end of the D-SUB cable to the 15-pin output connector on the video board of your computer.



4. Turn the monitor and the computer on.

If you wish to connect the monitor to an older-type Apple Macintosh, you need to use a Macintosh cable adapter to connect the video signal cable of your monitor to the video port of the computer. Your computer dealer should be able to supply you with a suitable adaptor.

Drivers for Windows 95, 98, 2000 and Millennium Edition

Windows will detect the Diamond View 1995SL monitor the first time you turn the computer on after installing it. The Add New Hardware wizard will prompt for drivers. Install the standard Windows *Plug & Play Monitor* driver. This driver will work correctly and allow you to use the monitor with its optimal resolutions and refresh rates.


A specific driver that includes the Windows ICC/ICM colour profile for the Diamond View 1995SL is available from Mitsubishi Electric Australia's web site at

http://www.mitsubishi-electric.com.au


Follow the link to the File Downloads/Monitors section of the site to download the drivers. Installation instructions are also available from at the monitor driver page.








You can adjust the monitor using its On-Screen Display (OSD) menu system. There are 5 buttons that control the monitor:



Selecting Functions and Making Adjustments

Contrast Hotkey

- 1. Press () to open the contrast adjustment display.
- 2. Press ◀ or ▶ to adjust the contrast level.
- 3. Press the **Exit** button to save your changes.



Brightness Hotkey


- 1. Press $-\dot{y}_{-}^{l}$ to open the brightness adjustment display.
- 2. Press ◀ or ▶ to adjust the contrast level.
- 1. Press the Exit button to save your changes.

The Main Menu


The Diamond View 1995SL's OSD has a in Main Menu organised into 6 groups of functions: Luminance, Geometry, Colour Adjustment, Recall, Degaussing and Miscellaneous. The remainder of this chapter describes the use of each function and the way that you can make adjustments to the image displayed on the monitor's screen.

Make adjustments

1. In Main Menu: Press ◀ or ▶ to select the function group with the item that you wish to change.



2. Press Enter to open the Sub Menu.



3. Press ◀ or ▶ to select the item to be changed and press Enter.

7

4. Press ◀ or ▶ again to make the adjustment.

* 🛛 😥 м	(A) etc	_	
Hor. Positio		_	Sub menu Function name Scale
Enter:Sa Exit : Ex			Enter:Save Exit : Exit

- 5. Press Exit to save the setting.
- 6. Press Exit to return to main menu.

	1. +	Luminance
●	Contrast	changes the difference between the light and dark areas of the displayed image.
-次-	Brightness	adjusts the brightness of the displayed image.

	2.	Geometry
	Hor. Position	adjusts the horizontal position of the image.
4 - >	Hor. Size	adjusts the image width.
	Ver. Position	adjusts the vertical position of the image.
\$	Ver. Size	adjusts the image height.
$\mathbf{\mathbf{x}}$	Rotation	corrects any tilting of the image.
$\sum $	Pincushion:	corrects curves in the vertical edges of the image.

	Unbalance	adjusts the pincushion balance if both sides of the image are bowed toward either the left or the right.
\square	Trapezoid	makes the vertical edges of the image parallel.
	Parallelogram	aligns the top and bottom edges of the image.
Г	Top corner	adjusts the edge curvature at the top corners of the image.
Д	Bottom corner	adjusts the edge curvature at the bottom corners of the image.



Colour Adjustment

Colour mode	Colour Temperature	Colour Temperature
	(Preset Mode)	(User Mode)
C1 (9300K)	9300K	User Mode 1
C2 (6500K)	6500K	User Mode 2

Colour Preset Mode: In this mode, C1 and C2 are two memory areas where the factory-preset colour settings are stored. These settings are fixed and can not be modified.

Colour User Mode: Press \P or \blacktriangleright to locate the colour mode and **Enter** to choose a colour. Press \P or \blacktriangleright again to make the adjustment. If you want to reset to preset modes, please locate $\blacktriangleright \P$ to recall the preset colour settings

4. Recall/Reset and Image Status

Select $\triangleright \triangleleft$ and press **Enter** to recall the factory settings for the current graphics signal. The word "Recall" will blink on the screen in the process of recall.

This page is also a status display that shows the horizontal and vertical frequencies of the current graphics signal. Please note that the resolution is only displayed if you are using a graphics signal that corresponds with one of the monitor's presets.

	5. 🔞	Manua	degaussing	function
To eliminate colour shading or impurity induced by magnetism. Press Enter to degauss the monitor. Use this function after moving the monitor or changing the direction that it is facing.				
	6. etc	Miscell	aneous	
	Hor. Moire	adjusts	horizontal Moir	é.
	Ver. Moire	adjusts	vertical Moiré.	
	If the picture is unstable when you adjust the Moiré reduction setting, over-adjustment has occurred. Please lower the Moire reduction setting level.			
	OSD position	change	s the OSD's po	sition.
ABC	OSD Language:			
	De : Deutsc	h	En :English	Es : Español
	Fr : Françai	S	It : Italiano	

Note:

- The setting of each parameter is represented by a numeric value and corresponding scale.
- The on-screen menu will automatically disappear after 20-second's of inactivity. If changes have been made, the monitor will automatically save them.

Timing and Refresh Rate Setting

By making adjustments of your video card settings, you can set the timing and the refresh rate to match your requirements. Please consult your operating system's and graphics adaptor's documentation for details about how this may be done.

The monitor will automatically save the changes that you make and use the new settings whenever you turn it on. The Diamond View 1995SL monitor can accept horizontal scanning frequencies ranging from 30 KHz to 95 kHz and vertical frequencies from 50 Hz to 160 Hz. However, due to the requirements of signals with different resolutions, and to avoid possible damage to your monitor, do not exceed the following maximum vertical refresh rates.

Resolution	Maximum Vertical Refresh Rate (Hz)
800 x 600	150
1024 x 768	118
1280 x 1024	88
1600 x 1200	76

Factory Preset Timings

Mode	Resolution	Vertical Frequency (Hz)	Horizontal Frequency (KHz)
Industry	640 x 400	70	31.47
Industry	640 x 480	60	31.47
VESA	800 x 600	75	46.88
VESA	800 x 600	85	53.67
VESA	1024 x 768	75	60.02
VESA	1024 x 768	85	68.68
VESA	1280 x 1024	75	79.98
VESA	1280 x 1024	85	91.15
VESA	1600 x 1200	65	81.25



If you encounter any trouble using the Diamond View 1995SL monitor, make sure that your monitor is properly installed. (For hardware installation, see Chapter 4 of this manual.) If the problems persist, please check this chapter for possible solutions before calling Mitsubishi Electric or one of our Authorised Service Centres.

No image is displayed

- Check that the light (LED) next to the monitor's power button is lit and is green in colour.
- If the LED is orange there is no signal from the computer and the monitor is in power saving mode. Check that the computer is switched on. Press a button on the computer keyboard or move the mouse to wake the computer. If that does not help, check that the VGA cable is securely plugged into the computer. Also check the pins of the VGA cable's connector. If any pins are bent or broken off, then contact your dealer.
- If the LED is not lit at all, check that the monitor is plugged into the power socket and that the power switch is turned on at the wall. Check that the monitor's power switch is also turned on.
- Video sync signal. The video sync signal from the graphics card must be as specified for the monitor.

The picture is scrolling or unstable.

- The most common cause of this problem is a loose VGA signal cable or connector. Check that the cable is securely connected to the computer.
- Check the VGA signal cable for damage. If any pins are bent or broken off, contact your dealer or an authorised Mitsubishi Electric service agent.
- Make sure that the graphics card settings are correct and within the monitor's specifications. Change the settings of your graphics card to values within the monitor's range.

- Remove any magnetic objects that are near the monitor. These include speakers and power supplies (AC adaptors).

Colours are impure.

- Check that the cable is securely connected to the computer.
- Check the VGA signal cable for damage. If any pins are bent or broken off, contact your dealer or an authorised Mitsubishi Electric service agent (see Chapter 11 for details).
- Check the monitor's colour settings. Press the Enter button and select the Color Settings menu. Select the Recall menu item to return to the factory preset colours and press Enter.
- Degauss the monitor using the degauss function of the monitor's On Screen Display.
- Remove any objects that can create a magnetic field that may be near the monitor. These include speakers and power supplies (AC adaptors).

The image is blurred or there is visible ghosting

- Have you used a VGA extension cable? If so, remove the extension cable and check the displayed image. Is the image quality improved? Depending on the characteristics and type of the extension cable, some blurring or distortion may occur due to conduction the extension cable. You can minimise these losses by using an extension cable with better conduction quality.
- Have you used a VGA splitter or a video amplifier? Depending on the characteristics and type of the splitter or amplifier some blurring or distortion may occur due to the limitations of the device's bandwidth. Problems caused by a limited bandwidth will increase as the signal's resolution and refresh rate increased. If you need to use a splitter or amplifier with you monitor, make sure that it is a good quality device that has sufficient bandwidth for the graphics resolution that you need to use.



<u>Model</u>

Diamond View 1995SL

Display Characteristics

Display Type

Maximum Viewable Size Dot pitch Surface coating 19" (48 cm) diagonal short-length cathode ray tube

18" (45.7cm) diagonal

0.26 mm

Anti-Glare, Anti-Reflective, Anti-Static coating

Graphics Signals

Maximum Resolution	1600 x 1200 pixels (at 75 Hz)
Recommended Resolution	1280 x 1024 pixels (at 85 Hz)
Horizontal Frequency	30 – 95 kHz
Vertical Frequency	50 - 160 Hz
Video Bandwidth	176 MHz
Microprocessor Controlled Graphics	9 factory preset timings
	15 user modes
Signal Connection	15-pin mini D-sub cable
Video Input	VGA-type (15 pin mini D-sub
	connector)
Video Signal	RGB analog (Positive polarity)
	0.7 Vpp/75 Ohm
Synchronisation	TTL separate, composite TTL
Plug & PLay	DDC-1, DDC-2B

User Interface

Controls

Mains power switch, On-Screen Display with 4 control buttons

On-Screen Display Functions:

Contrast; Brightness; Vert. & Hor. Image Position and Size; Pincushion Amplitude, Phase and Balance; Top and Bottom Corner Pincushion; Color Balance; Degauss; Horiz. and Vert. Moire; Choice of language (6 language OSD); OSD Position; Status Indicator

Physical Characteristics

Power Management	VESA DPMS, Energy Star
Maximum Power Consumption	120 Watts
Consumption in Power Saving Mode	< 15 Watts
	< 5 Watts
Operating Voltage	Automatic switched mode power supply, 100 - 240 V, 50 - 60 Hz
Dimensions (W x H x D)	455 x 476 x 416 mm
Weight	19 kg
Temperature (Operating/Storage)	5 °C ~ 40 °C / -20 °C ~ 60 °C
Air Humidity (Operating/Storage)	20% ~ 90% / 10% ~ 90%

Regulatory Certification

Safety	IEC 950, EN 60950 (TÜV/GS) AS/NZS 3260, UL1950, PTB
EMI/EMC	CSA, FCC Class B, AS/NZS 3548, VCCI
Other	TÜV/Ergonomics, FTZ Class B, DSNF, ISO 9241-3 -7 –8, CE Mark



If problems remain after checking this manual, please contact your place of purchase or contact

Australian Service Contacts

Visit the Mitsubishi Electric Australia web site at

www.mitsubishi-electric.com.au

For details of your nearest Mitsubishi Electric Authorised Service Centre or contact the Service Department for your state:

New South Wales and Australian Capital Territory

348 Victoria Road Rydalmere, NSW, 2116

Telephone: (02) 9684-7669

Fax: (02) 9684-7684

Queensland

1 / 104 Newmarket Road Windsor, Qld, 4030

Telephone: (07) 3357-8877

Fax: (07) 3357-8488

South Australia and Northern Territory

77 Port Road Hindmarsh, SA, 5007 Telephone: (08) 8340-0444

Fax: (08) 8340-0555

Victoria and Tasmania

4 / 303 Burwood Hwy East Burwood, Vic, 3151 Telephone: (03) 9262-9899

Fax: (03) 9262-9850

Western Australia

5 / 329 Collier Road Bassendean, WA, 6054

Telephone: (08) 9377-3411 Fax: (08) 9377-3499

New Zealand Service Contacts

Contact: Melco New Zealand Ltd. 1 Parliament St. Lower Hutt Wellington Telephone: (04) 560-9100

Fax: (04) 560-9140

Web site: www.melco.co.nz